

Selective Security Services

L2000/L3000/L6000 Surface Mount Installation Instructions

- 1) Prepare the surface for mounting. Find a flat wall or post location suitable for secure installation. Concrete or steel are the most secure.
- 2) Remove door and set aside

For hinged door models, open the door to install the lock box, being careful to avoid damage to the door or injury by allowing the door to swing shut on fingers.

Models with a tamper switch should have the switch removed during installation, to be reinstalled later.

- 3) Mark hole locations. Using a level, place the lock box on the wall in the desired location and mark hole locations using the holes in the back plate. Set the box aside and drill holes.
- 4) Mount the lock box with the arrow decal inside pointing up. The lock box is designed to be mounted with the bolt locking at the top.
- 5) Use four grade 5 or grade 8 bolts with an appropriate anchoring system to mount the lock box. It may also be welded onto a steel post for a very secure installation.
- 6) Apply weather proof caulk around the sides and top of the box, leaving the bottom uncaulked for drainage.
- 7) Reinstall tamper switch (if applicable), install and lock door to ensure proper fit.

